



Head protection

5050 BRACKET

FACE PROTECTION

Visor bracket replacement attachment -Attaches 5000 Bracket to Helmet for Use without Earmuff



Certifications and norms



Head protection

5050 BRACKET

FACE PROTECTION

Visor bracket replacement attachment -Attaches 5000 Bracket to Helmet for Use without Earmuff

Standards - Details

Technical details

Use	Inside/outside
Type of eye protection	Accessories